

EAGLE MANUFACTURING COMPANY
WELLSBURG, WV 26070
www.eagle-mfg.com

INSTALLATION INSTRUCTIONS FOR:

MODEL #1790-Y, -B, -G, -BLK PARKING STOP

These spikes are recommended for concrete and asphalt traffic surfaces.

For installation to concrete:

1. Position parking stop in its installation position on the traffic surface and mark the position of the 3 mounting holes on mounting surface. One suggestion would be to insert a spike into each mounting hole and tap head with hammer causing sharp tip to mark surface.
2. Remove the parking stop. With a high-speed hammer drill equipped with a $\frac{1}{2}$ " diameter masonry bit, drill a hole at each marked location through the concrete. Make sure holes are perpendicular to mounting surface.
3. Reposition parking stop in its installation position on the traffic surface. Insert spike through each hole in parking stop and start into drilled hole.
4. Finish installing each spike by driving it into concrete using a hammer weighing at least 3 pounds until just snug against top of unit.

For installation to asphalt:

1. Position parking stop in its installation position on the traffic surface.
2. Insert spike through each hole in parking stop and install each by driving it into asphalt using a hammer weighing at least 3 pounds, until just snug against top of unit.
(If necessary, drill holes in asphalt as outlined above.)